







THULE[®] SWEDEN Rapid Intracker

- GB** Fitting instructions
D Montageanleitung
F Instructions de montage
NL Montage-instructies
I Istruzioni per il montaggio
E Instrucciones de montaje
PT Instruções de Montagem
S Monteringsanvisning
FIN Asennusohje
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija
LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
RU Инструкции по установке
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
TR Montaj talimatları
中文 安装说明
日本語 取扱(取付)説明書
한국어 장착 지침
ไทย คำแนะนำการติดตั้ง

OPEL Astra, 5-dr Estate, 07-

OPEL Zafira, 5-dr MPV, 07-

HOLDEN Astra, 5-dr Estate, 07-

HOLDEN Zafira, 5-dr MPV, 07-

VAUXHALL Astra, 5-dr Estate, 07-

VAUXHALL Zafira, 5-dr MPV, 07-

4919

491900






Follow me...

852•30F/8F/501-7217-03


@ info@thule.com

www.thule.com
www.thuleprofessional.com



Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN




3



4






5



6







x2
16mm



7

x 1

x 4



S Demontering
GB Removal
D Demontieren
F Démontage
NL Demontage
FIN Irrotus

E Desmontaje
I Rimozione
CZ Odmontování
PL Wymontowywanie
HU Leszerelés
RU Снятие

EST Eemaldamine
SLO Odstranjevanje
 한국어 분리
 日本語 取り外し
 中文 拆除

